

VVA-MDE68 User Manual



2024 OCT V1.0



















(Optional)

CAUTION

Dear User:

The prompt and accurate services will be carried by the dealer. We will reserve the right to make any software or hardware modification and physical improvements to this series of products without making prior notice. Please read the manual carefully before using this product:

System Installation Precaution

- Please learn the electric wiring of the device before installation.
- Please select storage devices that are recommended by the dealer and meet the demands for the device to
 operate, to accomplish long-term IOPS needs with large amounts of data. Meanwhile, please purchase from
 certificated access to ensure the quality of the storage device.
- If you have any questions or require assistance, please get in touch with the Technician from the authorized dealer.

In-Vehicle system precaution

- Do not let any liquid or foreign material enter, drop or soak into the machine.
- Do not detach, repair or replace any components on one's own.
- If you encounter any malfunction, please contact the dealer or manufacturer, and we will provide solutions to cope within the smallest amount of time possible.

Operating Environment

- Please place or use this device under the operating temperature and avoid direct sunlight or being near heat.
- Do not place the device in humid or moist environment.
- Do not expose the device to smoking or dusty environment.
- Avoid strong collision and drop.
- Please install the device in a well-ventilated place and avoid any block to the vent.
- Please operate the device under the rated range of current and Voltage input and output.
- The device is a mechanization device design for long term use, do not place it near flammable or explosive items.

Menu

Operation precautions

Α.	Product Accessories	1
B.	Appearance	2
C.	Buttons Instruction	3
D.	Buttons and Indicator Lights	4
E.	4G-Ways to connect to GMS	5
F.	Memory Card Precaution	7
G.	WIFI connection (from APP)	8
Н.	Wi-Fi Web page Settings	16

A. Product Accessories


Please check the containing items for the following accessories before use.


Please contact the retailer if the containing items.


- This product contains the following accessories
 - 1. Body-cam*1
 - 2. Multi-turn Chest Clip*1
 - 3. Mini USB Charging Cable*1
- Optional
 - 1. IP/LAN Dock VVP-EB350 *1

B. Appearance


• Device










• LANDock







C. Buttons Instruction



D. Buttons and Indicator Lights

Function	Buttons	Operations	Indicators	
Power Supply	ტ	Press 2 seconds to boot. Press 5 seconds to shutdown. * Low-power alert: When the battery is lower than 10%, there will be a "beep" sound every 15 seconds as alert.	Recording indicator: Green flashes in every seconds. No indicator	
Audio Recording	•	When the device is on, short press to start the audio recording, and another press to end.	Recording indicator: Continuous orange light Front indicator: Continuous green light	
Fill Light	-₩-	One press to start light-filling, another press to end when the device is on.	No indicator The fill light will light continuously.	
Menu	=	When the device is on, Press 2 seconds to open the WiFi Web GUI service, and another 5 seconds to close it.	Red continuous light for recording indicator, power indicator and front Indicator	
Recording		When the device is on, short press to start recording and another press to end.	Recording indicator and Front indicator Flashes every two seconds.	
Snapshot	0	When in recording or none recording, Press to take a snapshot.	One orange flash on the Recording indicator, and one orange flash on the Front indicator.	
Emergency	sos	When the device is on, press two seconds to start recording and report to GMS, another press one the recording key to end.	Recording indicator and Front indicator Flashes every two seconds.	

Charging state	Device power indicator		
Charging	Red LED : Flash every seconds		
Charging complete	Red LED : Continuous lit		

E. 4G-Ways to connect to GMS

SIM card installation guideline

Insert the nano-SIM card into the MDE68 Card Slot. The SIM card will be fixed in the slot when it is placed and can be synced to the assigned server (gms.vacron.com).


(Way to retreat the SIM card: push the SIM card to the end with a tool to retreat the card from the card slot.)



IP							
	Full Hostname						
DHCP O		мти		1500			
			IP address	192.168.1.221]		
			Subnet mask	255.255.255.0]		
Static IP Static IP		Default Gateway IP		192.168.1.254			
		мти		1500			
		Enable					
	User Name						
3G/4G O	Password						
	Dial		*90#				
APN	internet						
DNS Assignment	Auto	O Manual					
Primary DNS Server	8.8.8.8			Secondary DNS Server			
WiFi							
	Enable	✓					
	SSID-068012						
			12345678				
Use Static IP in Cli	ent Mode						
	Channel	6					
E	ncryption						
WPA Cip	her Suite	□TKIP ☑AES					
WPA2 Cip	her Suite	OTKIP ZA	ES				
	LA	N IP 192.168.5	5.254				
	Subnet n	1ask 255.255.2	255.0				
Platform							
Server Add	iress 211	.75.207.242					
	Port 135	79					
MAC							
Factory Default MAC Address 62841B4D6BC7 Restore							
Current MAC Address							
Accept Reset Default							

To modify via the VACRON LINK APP, it is required to enter the WiFi name and password and open the settings server (it is defaulted to be closed).

Enter the server URL and port to modify.



F. Memory Card Precaution



CAUTION

- (1) It is recommended to format the device with the APP before use, otherwise, the device will erase all data in the memory disk before recording with the default setting.
- (2) There is a life span issue within the memory card, please check the memory card and play it on the App regularly, along with formatting the memory card to ensure it is still functioning.
- (3) Collision or high vibration may cause physical damage to the memory card and lead to stammering records or inability to play, please check and keep a backup for important data.

G. WIFI connection (from APP)

(a) Download vis QR Code:




VACRON LINK Android






(b) App operation:

- 1. Search "VACRON LINK" on APP store for downloading.
- 2. Open WiFi on the smartphone and connect to SSID-XXXXXX. Enter the default password 12345678.



3. Open "VACRON LINK", and click the "WiFi connection" in the main interface.



The image of the device will be shown after entering.

Click the red frame to start settings.




4. App main interface




Snapshot / Multi-split / Playback / Settings / Firmware update

5. Playback




Select the playback time stamp after clicking Playback to play the video.



Click the upper right to download

6. Firmware Update

Please make sure the file name is entered correctly, the path should be identical as shown in the picture.






7. APP Wi-Fi Settings




Click to enter.




WiFi settings / Device information / Versions / FPS
Bit-rate / Resolution
Specification / GPS_OSD / UID / MDVR_ID / Battery capacity
Memory card health status

Audio settings / Time correction / WiFi settings Server Configuration / Format the memory card / Default

8. Device information settings



9. FPS Settings



10. Bit rate Settings

Could select from 512k, 1M, 2M, 3M, 4M to 5M.


Click "Save" to save settings.




11. Resolution SettingsSupports 720P and 1080P




12. Specification Settings Supports NTSC / PAL



13. GPS OSD Settings



14. OSD Settings



15. Audio Settings

If wish to activate the audio settings, both sections in the red frame need to be switched on.



16. Time Correction




17. Change the WiFi name and password.

The name is preset as SSID-XXXX.

The name and password could be changed in this section.

The App will withdraw and reconnect after the setting.

New Wi-Fi name and password could be applied then.



18. Change the assigned server


It is required to enter the WiFi name and password and open the settings server (it is defaulted to be closed).

Enter the server URL and Port to modify.




19. Format the memory card

Click "Confirm" "to delete all datas.



20. Default Settings

Click "Confirm" "to restore default settings.



H. Wi-Fi Web page Settings


- (1) Open the WiFi mode via the device main menu.
- (2) The WiFi of the device (SSID-XXXX) will be shown on the computer WiFi.(A computer will require a WiFi SIM card to connect to WiFi)



(3) Enter 192.168.5.254 on IE to enter streaming.



Network Settings



Network Settings: For users to modify the connecting internal IP via IE.


WIFI: New WiFi name and password could be modified.

Platform: To activate the reporting function of the central server, send the camera image via the internet.

This function is only applied to devices with WiFi functions and users with built servers.

MAC: The section is reserved for the manufacturer to check the producing date and the model number.

Image Settings



Can modify the resolution / frame rate / data rate / illumination control


Resolution: Supports 720P and 1080P

Frame Rate: Supports 5/10/15/20/25/30

Data Rate: Supports 512K / 1024K / 2048K / 3072K / 4096K

Illumination control: 60HZ/ 50HZ/ OFF

Audio Settings




Could modify the input/output audio gain.



https://www.vacron.com.tw


Made in Taiwan

User account




Set the user account and password.

Playback




View the playbacks and download recordings, the snapshot images can be viewed below.

Firmware update



There will be various upcoming updates firmware on the VACRON official website, please download the latest version of firmware to update if required.

Reactivate



For reactivating the device, there will be 50 seconds of waiting time after selecting.

Language



Can switch the languages by the pull-down list.



- (1) Live streaming may lag due to wireless transmitting and receiving.
- (2) The remote operation function is limited to only the data in the storage device. If the data in the SD card has been overwritten, the data for that period cannot be searched.
- (3) When the operation is over, please remember to disconnect the WiFi connection with the machine; otherwise, the mobile phone will not connect to the external network.
- (4) If there is no head-up display indicator, it is recommended to regularly check and use a computer to play images to ensure the regular operation of the recording system.